



## HLP-L



### HL TELEPHONE PLUG



Use with line cord.

## HLJ-L



### HL TELEPHONE JACK



Use with line cord.

## HLPJ-L



### HL PLUG/JACK ADAPTER



Use with line cord.  
Converts a single outlet jack into a plug/jack adapter.

## HLOPJ-L



### HL PLUG/JACK ADAPTER(Break in)























Use with line cord, plug and jack are separated.

## HLSJ-L

### HL SURFACE JACK





Use with line cord.

<b>HLP-MJ</b>		<b>HL PLUG WITH US JACK</b>		Male plug to US modular jack.
				
<b>HLJ-MJ</b>		<b>HL JACK WITH US JACK</b>		Female jack to US modular jack.
				
<b>HLPJ-MJ</b>		<b>HL ADAPTER WITH US JACK</b>		Plug & jack to US modular jack.
				
<b>HLOPJ-MJ</b>		<b>HL ADAPTER WITH US JACK (Break in)</b>		Plug and jack are separated.
				
<b>HLSJ-MJ/L</b>		<b>HL SURFACE JACK WITH US JACK</b>		Surface jack to US modular jack use with line cord.
				

## HLP-402-MP



### HLP TO US PLUG WITH 2M 4C CORD



HLP-404-MP (4C 4M)  
HLP-406-MP (4C 6M)  
HLP-410-MP (4C 10M)

## HLPJ-402-MP



### HLPJ TO US PLUG WITH 2M 4C CORD



HLPJ-404-MP (4C 4M)  
HLPJ-406-MP (4C 6M)  
HLPJ-410-MP (4C 10M)

## HLP-402-MJ



### HLP TO US JACK WITH 2M 4C CORD



HLP-404-MJ (4C 4M)  
HLP-406-MJ (4C 6M)  
HLP-410-MJ (4C 10M)

## HLP-402-MJ2



### HLP TO DUAL US JACK WITH 2M 4C CORD



HLP-404-MJ2 (4C 4M)  
HLP-406-MJ2 (4C 6M)  
HLP-410-MJ2 (4C 10M)



## HLP-402-HLJ

### HLP TO HLJ WITH 2M 4C CORD





HLP-404-HLJ (4C 4M)  
HLP-406-HLJ (4C 6M)  
HLP-410-HLJ (4C 10M)

## HLPJ-402-HLJ HLPJ TO HLJ WITH 2M 4C CORD





HLPJ-404-HLJ (4C 4M)  
HLPJ-406-HLJ (4C 6M)  
HLPJ-410-HLJ (4C 10M)

## HLP-402-HLSJ HLP TO HLSJ WITH 2M 4C CORD





HLP-404-HLSJ (4C 4M)  
HLP-406-HLSJ (4C 6M)  
HLP-410-HLSJ (4C 10M)

## HLP-402-HLSJ/MJ HLP TO HLSJ/MJ WITH 2M 4C CORD





HLP-404-HLSJ/MJ (4C 4M)  
HLP-406-HLSJ/MJ (4C 6M)  
HLP-410-HLSJ/MJ (4C 10M)

## HLPJ-402-HLSJ HLPJ TO HLSJ WITH 2M 4C CORD



HLPJ-404-HLSJ (4C 4M)  
HLPJ-406-HLSJ (4C 6M)  
HLPJ-410-HLSJ (4C 10M)

## HLPJ-402-HLSJ/MJ HLPJ TO HLSJ/MJ WITH 2M 4C CORD



HLPJ-404-HLSJ/MJ (4C 4M)  
HLPJ-406-HLSJ/MJ (4C 6M)  
HLPJ-410-HLSJ/MJ (4C 10M)